

Portable Fuel Integrity Test Kit



- Suitable for Jet Fuel and other distillate fuels
- Rapid check for presence of contamination
- Multiple tests in single kit
- Compact, easy to carry rucksack
- Ideal for shipboard use

A self contained kit of test equipment for rapid detection of contamination in fuels. The kit has been designed to fit into a small purpose made rucksack enabling it to be easily transported to test sites which have only limited or difficult access. It is ideally suited for shipboard use providing both rapid and easy verification of product integrity prior to off-loading.

The kit comprises of 5 key tests that allow go/no go testing of fuels;

- **Flashpoint (ASTM D3828)** - using the Series 3 Closed cup tester, complete with syringes and portable gas supply. (Note - An external mains power supply is required for this instrument)
- **Density** - An ATEX approved digital density meter
- **Conductivity (ASTM D2624)** - Using a digital conductivity meter
- **Water Content** - Shell Water Capsules offer detection to 30ppm (80 tests & syringes)
- **Digicell** - Digital readout of Water content, 100-3000ppm, 200-10000ppm and 0-10% (50 tests)

SPECIFICATIONS

| | |
|--------------|----------------|
| Part Number | 86400-0 |
| Size (HxWxD) | 30 x 30 x 30cm |
| Weight | 6.5kg |