

Automatic Dielectric Oil Tester

AS 1767; ASTM D1816; ASTM D877; BS 5874; CEI 344; FTM 791 5702; IEC 156; IP 295; NFC 27; NFC 27-221; rOCT5861; SABS 555; VDE 0370

- Automatic test sequence
- Pre-set and user defined programs
- Bluetooth connection and USB drive
- Fully interlocked
- Multi language

The Seta Dielectric Oil Tester is the smallest and lightest portable oil test set of its rating available. The 2.8" colour display is very bright and offers optimal readability and mobility. Ultra fast switch-off time at flash over (<math><5\mu\text{s}</math>) - especially important for silicon oils. Direct measurement of output voltage. The built-in printer offer a direct evaluation and reporting of the results. Communications via Bluetooth and/or USB Flash Drive.

Supplied with test vessel and mushroom electrodes for IP 295, IEC 60 156 (VDE).



Specifications:	
Part Number:	99620-3
Test Voltage:	100kV
Voltage:	110/120V, 50/60Hz 220/240V 50/60Hz
Size (HxWxD):	52x34x30 cm
Weight:	32 kg